



N° pièce	Description pièce	Référence
1	Protection lame	0317TJ195B1
2	Vis	0317TJ195B2
3	Lame	0317TJ195B3
4	Ensemble axe poulie	0317TJ195B4
7	Courroie	0317TJ195B7
10	Vis de blocage	0317TJ195B10
11	Vis	0317TJ195B11
12	Barre de fixation moteur	0317TJ195B12
13	Fixation poignée	0317TJ195B13
14	Affuteur	0317TJ195B14
15	Vis	0317TJ195B15
18	Bague	0317TJ195B18
23	Fixation	0317TJ195B23
24	Protection lame	0317TJ195B24
27	Vis de fixation	0317TJ195B27
30	Couvercle	0317TJ195B30
31	Bague	0317TJ195B31
32	Base	0317TJ195B32
33	Plaque	0317TJ195B33
34	Anneau	0317TJ195B34
35	Bague	0317TJ195B35
36	Plateau	0317TJ195B36
37	Fixation plateau	0317TJ195B37
38	Arbre	0317TJ195B38
39	Pièce d'ajustement	0317TJ195B39
40	Vis	0317TJ195B40
41	Plaque de verrouillage	0317TJ195B41
42	Interrupteur	0317TJ195B42
44	Plaque inférieure	0317TJ195B44
45	Molette taille de coupe	0317TJ195B45
46	Embase molette	0317TJ195B46
47	Pieds	0317TJ195B47
48	Barre	0317TJ195B48
49	Barre	0317TJ195B49
50	Ressort	0317TJ195B50
54	Protection plastic	0317TJ195B54
55	Plateau	0317TJ195B55
56	Bague	0317TJ195B56
57	Bras de maintien	0317TJ195B57
58	Barre	0317TJ195B58
60	Poignée	0317TJ195B60
61	Moteur	0317TJ195B61
62	Vis	0317TJ195B62
63	Câble d'alimentation	0317TJ195B63
64	Vis	0317TJ195B64
65	Vis	0317TJ195B65

